



# WAFFLE PROGRAM – FAQs

## Good practices.

Use a waffle fork to remove waffles from the machine to avoid scratching the nonstick coating. Never use a metal utensil.

Use a cleaning brush to thoroughly clean plates without scratching.



## WAFFLES STICKING?

Waring Waffle Makers are equipped with a nonstick coating to prevent waffles from sticking. However, if sticking begins to occur, use soft bristle or silicone brush to evenly coat plates with cooking oil. We do not recommend using nonstick spray because, if used over time, it will cause a buildup of plate tackiness.

### Buildup on plates? Plates scratched?

Plates are removable and can be easily replaced on location.

**Order – WW180XRP/WWD180XRP/WBW300XRP/WMB400XRP**

Includes: 1 top plate + 1 bottom plate per kit plus screws and screwdriver

## Waring – The Works: How to Replace Waffle Plates



[Watch Here](#)

### For Repairs, Customer Service and Questions

Weekdays 8:30am – 4:30pm EST

Call: 1-800-4WARING • Email: [waringproductsupport@conair.com](mailto:waringproductsupport@conair.com)

Unplug and allow Waffle Maker to cool completely before cleaning.

**DAILY STEPS**

**STEP 1**




**TIP**  
Only use brushes with soft bristles to avoid scratching the nonstick coating.

**STEP 2**



**STEP 3**



**STEP 4**



Patrons will often overfill the waffle makers, which causes batter to overflow. To prevent staining on the exterior of the unit, it is important to clean the housing periodically throughout each day of service.

**EVERY 3–4 MONTHS**

For busy establishments, it may be necessary to replace waffle plates over time. To replace plates, order through Waring customer service at 1-800-4WARING, order online or find a local distributor or service center.

NOTE: Any other servicing should be performed by an authorized service representative.

WAFFLE MAKER	REPLACEABLE PLATE
WW180X – Belgian	WW180XRP
WWD180X – Classic	WWD180XRP
WMB400X – Mini Belgian	WMB400XRP
WW250X2/BX2 – Side-by-Side Belgian	WW180XRP*
WBW300X – Bubble	WBW300XRP

\*Need to order 2 kits to replace full unit

Plates should not be removed for cleaning. Waffle plates are not dishwasher safe.